

TT dead pedal mod for Corrado by zarman

[my email](#)

Materials:

Dead pedal
Pedal mounting bracket
2 x L-shaped brackets
8 x 3/4 inch bolts
16 x nuts



The first step is to mark the position of the dead pedal (with mounting bracket) to the plastic side panel under the hood release lever. This should be done with the side panel still in the car (and not outside the car as the picture shows). Hold the pedal in place and angle it the way you want it. With a pencil, draw a line (using the pedal as a ruler) to side of the plastic panel to mark the the pedal's position. Remove the panel cover from the car.



Second step: With the dead pedal removed from the pedal bracket, position the L-brackets to the dead pedal bracket as shown. Drill holes for the bolts and bolt the L-brackets to the back of the pedal bracket. Use double nuts to tighten. Put the dead pedal back on its mounting bracket and position it to where the mark was left on the side panel so that it's in the same position as was measured. Mark where you need to drill the bolts to attach. Drill and attach the bolts to the side of the panel.



Step three: Picture shows the back of the side panel and the bolt attachments. Once the dead pedal and mounting base is attached to the side panel, reattach the whole unit back into the car. You will notice that a large plastic screw that was used to attach the side panel to the floor is no longer accessible since the dead pedal is now covering it. It will have to do without it.

You are done!



